

AD-A195 488

AUTOMATIC PROBER FOR THE DC CHARACTERISATION OF GALLIUM 1/1

ARSENIDE DEVICES (U) ROYAL SIGNALS AND RADAR

ESTABLISHMENT MALVERN (ENGLAND) J. I. HUGHES ET AL


UNCLASSIFIED

JUL 87 RSRE-MEMO-4866-PT-2 DRIC-DR-185535

F/C 28/12

NL

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
742  
743  
744  
745  
746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760  
761  
762  
763  
764  
765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
957  
958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969  
970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011  
1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024  
1025  
1026  
1027  
1028  
1029  
1030  
1031  
1032  
1033  
1034  
1035  
1036  
1037  
1038  
1039  
1040  
1041  
1042  
1043  
1044  
1045  
1046  
1047  
1048  
1049  
1050  
1051  
1052  
1053  
1054  
1055  
1056  
1057  
1058  
1059  
1060  
1061  
1062  
1063  
1064  
1065  
1066  
1067  
1068  
1069  
1070  
1071  
1072  
1073  
1074  
1075  
1076  
1077  
1078  
1079  
1080  
1081  
1082  
1083  
1084  
1085  
1086  
1087  
1088  
1089  
1090  
1091  
1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142  
1143  
1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179  
1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1198  
1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291  
1292  
1293  
1294  
1295  
1296  
1297  
1298  
1299  
1300  
1301  
1302  
1303  
1304  
1305  
1306  
1307  
1308  
1309  
1310  
1311  
1312  
1313  
1314  
1315  
1316  
1317  
1318  
1319  
1320  
1321  
1322  
1323  
1324  
1325  
1326  
1327  
1328  
1329  
1330  
1331  
1332  
1333  
1334  
1335  
1336  
1337  
1338  
1339  
1340  
1341  
1342  
1343  
1344  
1345  
1346  
1347  
1348  
1349  
1350  
1351  
1352  
1353  
1354  
1355  
1356  
1357  
1358  
1359  
1360  
1361  
1362  
1363  
1364  
1365  
1366  
1367  
1368  
1369  
1370  
1371  
1372  
1373  
1374  
1375  
1376  
1377  
1378  
1379  
1380  
1381  
1382  
1383  
1384  
1385  
1386  
1387  
1388  
1389  
1390  
1391  
1392  
1393  
1394  
1395  
1396  
1397  
1398  
1399  
1400  
1401  
1402  
1403  
1404  
1405  
1406  
1407  
1408  
1409  
1410  
1411  
1412  
1413  
1414  
1415  
1416  
1417  
1418  
1419  
1420  
1421  
1422  
1423  
1424  
1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448  
1449  
1450  
1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459  
1460  
1461  
1462  
1463  
1464  
1465  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475  
1476  
1477  
1478  
1479  
1480  
1481  
1482  
1483  
1484  
1485  
1486  
1487  
1488  
1489  
1490  
1491  
1492  
1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506  
1507  
1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515  
1516  
1517  
1518  
1519  
1520  
1521  
1522  
1523  
1524  
1525  
1526  
1527  
1528  
1529  
1530  
1531  
1532  
1533  
1534  
1535  
1536  
1537  
1538  
1539  
1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564  
1565  
1566  
1567  
1568  
1569  
1570  
1571  
1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580  
1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591  
1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622  
1623  
1624  
1625  
1626  
1627  
1628  
1629  
1630  
1631  
1632  
1633  
1634  
1635  
1636  
1637  
1638  
1639  
1640  
1641  
1642  
1643  
1644  
1645  
1646  
1647  
1648  
1649  
1650  
1651  
1652  
1653  
1654  
1655  
1656  
1657  
1658  
1659  
1660  
1661  
1662  
1663  
1664  
1665  
1666  
1667  
1668  
1669  
1670  
1671  
1672  
1673  
1674  
1675  
1676  
1677  
1678  
1679  
1680  
1681  
1682  
1683  
1684  
1685  
1686  
1687  
1688  
1689  
1690  
1691  
1692  
1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702  
1703  
1704  
1705  
1706  
1707  
1708  
1709  
1710  
1711  
1712  
1713  
1714  
1715  
1716  
1717  
1718  
1719  
1720  
1721  
1722  
1723  
1724  
1725  
1726  
1727  
1728  
1729  
1730  
1731  
1732  
1733  
1734  
1735  
1736  
1737  
1738  
1739  
1740  
1741  
1742  
1743  
1744  
1745  
1746  
1747  
1748  
1749  
1750  
1751  
1752  
1753  
1754  
1755  
1756  
1757  
1758  
1759  
1760  
1761  
1762  
1763  
1764  
1765  
1766  
1767  
1768  
1769  
1770  
1771  
1772  
1773  
1774  
1775  
1776  
1777  
1778  
1779  
1780  
1781  
1782  
1783  
1784  
1785  
1786  
1787  
1788  
1789  
1790  
1791  
1792  
1793  
1794  
1795  
1796  
1797  
1798  
1799  
1800  
1801  
1802  
1803  
1804  
1805  
1806  
1807  
1808  
1809  
1810  
1811  
1812  
1813  
1814  
1815  
1816  
1817  
1818  
1819  
1820  
1821  
1822  
1823  
1824  
1825  
1826  
1827  
1828  
1829  
1830  
1831  
1832  
1833  
1834  
1835  
1836  
1837  
1838  
1839  
1840  
1841  
1842  
1843  
1844  
1845  
1846  
1847  
1848  
1849  
1850  
1851  
1852  
1853  
1854  
1855  
1856  
1857  
1858  
1859  
1860  
1861  
1862  
1863  
1864  
1865  
1866  
1867  
1868  
1869  
1870  
1871  
1872  
1873  
1874  
1875  
1876  
1877  
1878  
1879  
1880  
1881  
1882  
1883  
1884  
1885  
1886  
1887  
1888  
1889  
1890  
1891  
1892  
1893  
1894  
1895  
1896  
1897  
1898  
1899  
1900  
1901  
1902  
1903  
1904  
1905  
1906  
1907  
1908  
1909  
1910  
1911  
1912  
1913  
1914  
1915  
1916  
1917  
1918  
1919  
1920  
1921  
1922  
1923  
1924  
1925  
1926  
1927  
1928  
1929  
1930  
1931  
1932  
1933  
1934  
1935  
1936  
1937  
1938  
1939  
1940  
1941  
1942  
1943  
1944  
1945  
1946  
1947  
1948  
1949  
1950  
1951  
1952  
1953  
1954  
1955  
1956  
1957  
1958  
1959  
1960  
1961  
1962  
1963  
1964  
1965  
1966  
1967  
1968  
1969  
1970  
1971  
1972  
1973  
1974  
1975  
1976  
1977  
1978  
1979  
1980  
1981  
1982  
1983  
1984  
1985  
1986  
1987  
1988  
1989  
1990  
1991  
1992  
1993  
1994  
1995  
1996  
1997  
1998  
1999  
2000  
2001  
2002  
2003  
2004  
2005  
2006  
2007  
2008  
2009  
2010  
2011  
2012  
2013  
2014  
2015  
2016  
2017  
2018  
2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040  
2041  
2042  
2043  
2044  
2045  
2046  
2047  
2048  
2049  
2050  
2051  
2052  
2053  
2054  
2055  
2056  
2057  
2058  
2059  
2060  
2061  
2062  
2063  
2064  
2065  
2066  
2067  
2068  
2069  
2070  
2071  
2072  
2073  
2074  
2075  
2076  
2077  
2078  
2079  
2080  
2081  
2082  
2083  
2084  
2085  
2086  
2087  
2088  
2089  
2090  
2091  
2092  
2093  
2094  
2095  
2096  
2097  
2098  
2099  
2100  
2101  
2102  
2103  
2104  
2105  
2106  
2107  
2108  
2109  
2110  
2111  
2112  
2113  
2114  
2115  
2116  
2117  
2118  
2119  
2120  
2121  
2122  
2123  
2124  
2125  
2126  
2127  
2128  
2129  
2130  
2131  
2132  
2133  
2134  
2135  
2136  
2137  
2138  
2139  
2140  
2141  
2142  
2143  
2144  
2145  
2146  
2147  
2148  
2149  
2150  
2151  
2152  
2153  
2154  
2155  
2156  
2157  
2158  
2159  
2160  
2161  
2162  
2163  
2164  
2165  
2166  
2167  
2168  
2169  
2170  
2171  
2172  
2173  
2174  
2175  
2176  
2177  
2178  
2179  
2180  
2181  
2182  
2183  
2



MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A

AD-A195 408

ROYAL SIGNALS AND RADAR ESTABLISHMENT

Memorandum 4066

Title: AUTOMATIC PROBER FOR THE DC CHARACTERISATION OF  
GALLIUM ARSENIDE DEVICES:- PART TWO, THE DATA SORTING  
AND DISPLAY FACILITY

Authors: B T Hughes and B E Avery

Date: July 1987

ABSTRACT

The Automatic Device Probing System used in the Microwave Devices Division (DP2) comprises separate measurement and data handling facilities. the measurement facility is described in RSRE Memorandum 4065 and the data sorting and display facility forms the subject of this memorandum.

The facility described is designed to assist in analysing the large quantity of measured data obtained from device wafers and allows general trends as well as individual device parameters to be investigated. Programs have been written to produce maps which allow parameter variations across wafers to be assessed and additional routines are available which present the data in histogram form. These options allow the numeric as well as the geographic distribution of the data to be investigated. Three main types of map display are available, these display the variation in magnitude of a device parameter across a wafer, the location and nature of the failure of any failed devices and the location of devices with a specified combination of parameters. The histogram programs allow the data range and class interval to be adjusted enabling estimates of yield and process control to be made. For measurements such as Capacitance/Voltage on Schottky test patterns or current/voltage on active devices plots of the measured data can be displayed. Routines are available which allow curve fitting to the measured data so that barrier heights etc can be extracted.

Full use has been made of colour and grey scales in order to maximise the visual content of the information presented on the display screen and all display modes are easily selected using a combination of menus and softkeys.

Copyright  
C  
Controller HMSO London  
1987



Accession For	
NTIS CRA&I	<input checked="checked" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution /	
Availability Codes	
Dist	Avail and/or Special
A-1	

AUTOMATIC PROBER FOR THE DC CHARACTERISATION OF GALLIUM ARSENIDE  
DEVICES

PART TWO :- THE DATA SORTING AND DISPLAY FACILITY

CONTENTS

- 1) INTRODUCTION
- 2) HARDWARE DESCRIPTION
- 3) DISPLAY OPTIONS
  - i) General
  - ii) Histograms
  - iii) Maps
  - iv) Scatter Plots
- 4) MEASUREMENT DETAILS
  - i) Resistance
  - ii) Capacitance
  - iii) Transmission Line Ohmic Measurements
  - iv) Field Effect Transistors
  - v) Detailed FET Characteristics
  - vi) Diode Forward Characteristics
  - vii) C/V Profiling
- 5) SOFTWARE DESCRIPTION
  - i) General
  - ii) Histogram Plotting
  - iii) Grey Scale Maps
  - iv) Selection Maps
  - v) Scatter Plotting
  - vi) Failure Maps
  - vii) C/V Measurements
  - viii) Detailed FET V/I
  - ix) Diode Forward I/V
  - x) Transmission Line Ohmic Measurements
  - xi) Data Conversion
- 6) CONCLUSIONS
- 7) ACKNOWLEDGEMENTS
- 8) REFERENCES

AUTOMATIC PROBER FOR THE DC CHARACTERISATION OF  
GALLIUM ARSENIDE DEVICES

PART TWO :- THE DATA SORTING AND DISPLAY FACILITY

1) INTRODUCTION

RSRE Memo No 4065 described the measurement aspects of the DP2 prober system. This memo describes the data handling aspects of the system and, where applicable, defines the device parameters being analysed.

The initial version of the autoprober system used the same computer to both control the measuring system and sort and display the measured data. This system soon proved to be a major bottleneck in wafer processing as the HP86 computer used was relatively slow in sorting and displaying the data and a queue of wafers waiting to be probed soon built up. An additional demand on the system was caused by the enthusiasm with which the processing teams adopted the wide range of measurements available. It was also realised during this period that computer printers and plotters were not necessarily clean room compatible. Owing to these factors it was decided to separate the two functions of the probing system and construct a separate data handling and display facility outside the clean area. The computer used for this facility was chosen to be better suited to the data handling and display requirements. A separate suite of software was written to take full advantage of the extra sophistication and speed for which the need had become apparent.

The computer system on which this facility is based is described in section two of this memo. The various options available for displaying the data are described in section three. Section four of this memo describes the specific details of the individual measurements and section five describes the software used for data handling, parameter extraction and display. A full software listing is given in a separate Appendix.

2) HARDWARE DESCRIPTION

COMPUTER:- Hewlett Packard 9000 Series 300

Technical computer fitted with 3 Mbyte of random access memory. The primary operating system is BASIC version 4.0. The display system is bit-mapped and a 12 inch colour monitor is fitted. A Hewlett Packard 9122D 3.5 inch disc drive is used for program and data storage. Operator input is either by keyboard or mouse.

PLOTTER:- Hewlett Packard 7475A 6 pen graphic plotter.

PRINTERS:- Hewlett Packard 2225A Thinkjet matrix printer,  
used for screen dumping.

Epson FX100, used for printed data output.

### 3) DISPLAY OPTIONS

#### i) GENERAL

In order to make full use of the data available it was decided that the general approach would be to attempt to combine facilities for obtaining an overall impression of device parameters with the ability to select and display data down to individual device level. A consequence of this approach is that a large amount of computer storage is required so that complete data files can be stored in RAM ready for immediate access. Storage is also required for parameters derived from the measured data. A strong emphasis was placed on the visual presentation of data with full colour and grey scale displays considered essential. As the system would be available for general use a menu driven system was designed with all commands entered using softkeys. The particular display options required for different data sets are automatically selected by the computer.

#### ii) HISTOGRAMS

The most straightforward way of indicating the range and distribution of a set of data is to display it in histogram form. The histogram program written for this system automatically scales the X axis from zero to the maximum value measured and selects a large box size to give an initial display of all the data gathered, figure (1). Options are then made available to reduce the box size and select alternative maximum and minimum values for the X and Y axes. Figure (2) shows a selected region of figure (1) and demonstrates the effect of reducing the box size and restricting the data range.

All histogram plots contain a data panel down the right hand side of the display. The parameters displayed in this data panel are defined below and are illustrated with an example based on a wafer containing a 10 x 10 array of FETs with the probe commanded to probe a 10 x 11 array.

#### a) BOXSIZE

The size of the class interval used to produce the histogram being displayed.

b) COLUMNS

The number of devices in the X direction the prober was commanded to probe. In the example COLUMNS = 10.

c) ROWS

The number of devices in the Y direction the prober was commanded to probe. In the example ROWS = 11.

d) OFF WAFER

The number of times the prober edge detector indicated an off wafer condition during the probing run. In the example the eleventh row is assumed to be off the wafer and:-

OFF WAFER = 10.

e) TOTAL PROBED

The actual number of device sites probed ie:-

(COLUMNS X ROWS) - OFF WAFER.

This parameter takes account of the fact that although the prober table movements are defined as a rectangular array most wafers are circular or semi-circular.

In the example OFFWAFER = 10 therefore:-

TOTAL PROBED = (10 x 11) - 10 = 100.

f) NUMBER PLOTTED

The total number of data points occurring in the data range selected, ie the sum of the class frequencies of all the boxes displayed on the associated histogram plot. It should be noted that NUMBER PLOTTED will vary as the Xmax and Xmin values are altered.

If, in the example, we assume that Idsso is being plotted over the data range from 20 to 40 mA and that 10 devices have Idsso values between 20 and 40 mA, then:-

NUMBER PLOTTED = 10.

g) OVERALL YIELD

During probing a number of tests are carried out on the data being obtained. Only those devices which



pass all the relevant tests are classed as successful devices. The DEVICE YIELD is defined as "the total number of devices on the wafer which lie within all the default failure limits operating during probing".

$$\text{The OVERALL YIELD} = \frac{\text{DEVICE YIELD}}{\text{TOTAL PROBED}} \times 100\%$$

If, in the example, it is assumed that a total of 30 FETs, out of the 100 possible, passed all the probing tests then the DEVICE YIELD = 30 and:-

$$\text{OVERALL YIELD} = \frac{30}{100} \times 100\% = 30\%.$$

h) DISPLAY YIELD

This relates to the particular device parameter being displayed and is defined as:-

$$\text{DISPLAY YIELD} = \frac{\text{NUMBER PLOTTED}}{\text{TOTAL PROBED}}$$

If, in the example, we assume that 15 FETs failed any one of the measurements preceeding the Idsso measurement and if we also assume that a further 25 FETs failed during the Idsso measurement then, at the conclusion of the Idsso measurement, a total of 40 FETs have failed (ie 15 + 25). Of the 100 devices possible on the example wafer 60 are therefore left at the conclusion of the Idsso measurement.

If the Idsso histogram is plotted for the complete data range then:-

$$\text{DISPLAY YIELD} = \frac{60}{100} \times 100\% = 60\%$$

If the data range of the histogram is altered to cover the range from 20 mA to 40 mA and if 10 FETs have Idsso values within this range then in this case:-

$$\text{DISPLAY YIELD} = \frac{10}{100} \times 100\% = 10\%$$

i) MAXIMUM

The maximum value measured for the particular parameter being displayed.

j) MINIMUM

The minimum value measured for the particular parameter being displayed.

k) MEAN

The arithmetic mean of all the data points within the data range selected.

ie: 
$$\frac{\text{(The sum of the data points between x max and x min)}}{\text{NUMBER PLOTTED}}$$

l) STANDARD DEVIATION

The standard deviation of all the data points within the range selected.

$$\text{Std. Dev.} = (\bar{x}^2 - (\bar{x})^2)^{\frac{1}{2}}$$

iii) MAPS

In order to fully assess any process, or combination of processes, it is necessary to examine the geographic distribution of the measured device parameters as well as the numeric distribution. Three types of map display are available, these show the geographic distribution of the numeric data, the geographic distribution of the failure modes of any failed devices and the geographic distribution of devices with a specified set of electrical parameters.

a) GREY SCALE MAP

This facility enables the geographic distribution of the numeric data to be displayed. The wafer data is examined device by device and each device is allotted a grey scale intensity which is related to the measured value of the device parameter being investigated. The grey scale map is drawn with each device represented by a rectangle, the intensity of the rectangle corresponds to the magnitude of the parameter and the relative position of the rectangle on the screen corresponds to the original position of the device on the wafer. Owing to printer limitations only seven grey scales are available to cover the range from black to white so the data is always sorted into seven consecutive classes with each class size equal to one seventh of the data range. The initial grey scale map drawn when this mode of display is selected has a data range between the minimum and maximum measured values of the parameter being displayed, figure (3). Subsequent maps can be drawn with data ranges selected in the same fashion as in the histogram mode. Figure (4) and figure (5) show how the distribution of the data can be highlighted with judicious control of the data range.

An additional feature of the map drawing program is also illustrated in these figures. Because the device X and Y pitches on the wafer are not necessarily

equal the resultant map display, drawn using the same X and Y scales, can be elliptical rather than circular. A facility exists to allow different X and Y scales to be used for drawing, this results in the more representative displays shown.

b) FAILURE MAP

As described in RSRE Memo 4065 the probing program contains a number of built in pass/fail tests for all device parameters measured. All failures are identified with a specific token which is stored in the array containing the measured data. The failure map makes use of these tokens and draws a colour map of the wafer with specific colours associated with specific parameter failures. An example of a failure map is shown in figure (6).

c) SELECTION MAP

A useful facility, when selecting devices for RF testing, is the ability to specify an envelope of device parameters and then identify where those devices which lie within this envelope are located on the wafer. Figure (7), Figure (8) and Figure (9) show selection maps of the same wafer of FETs in which  $I_{dss}$  ranges of 20 to 30 mA, 30 to 40 mA and 40 to 50 mA have been used as a single selection parameter. The selection program allows any number of parameters to be combined to form a "device specification" or "device template". In addition to the map display a printer output of the measured DC parameters of all devices selected can be obtained.

This facility can also be used to assess the device yield on a wafer using more realistic pass/fail criteria than the very broad ones used during device probing.

iv) SCATTER PLOTS

This option operates on FET data only and allows any two measured FET parameters to be plotted against each other. An example of a scatter plot is shown in figure (10). Facilities are available to plot the data on logarithmic scales and select the data ranges for the X and Y axis.

#### 4) MEASUREMENT DETAILS

##### i) RESISTANCE

This measurement option is usually used to determine the resistivity of the various metals deposited to form ohmic or Schottky contacts or interconnect tracks. It should be noted that although a four probe measurement technique is used allowance must be made, when interpreting the results, for parasitic series resistances due to the difficulty of placing the probes reproducibly and exactly.

The display options available include histograms, grey scale maps, selection maps and failure maps.

##### ii) CAPACITANCE

All capacitance measurements are carried out in the parallel equivalent circuit mode and values of capacity and conductance obtained. It should be noted that a parasitic probe contact resistance is always present owing to the two probe measurement circuit used.

Display options available include histograms, grey scale maps, selection maps and failure maps.

##### iii) TRANSMISSION LINE OHMIC MEASUREMENTS

This measurement is carried out using the 4 probe configuration described in the RESISTANCE section. Definitions of the parameters obtained are given below:-

###### a) CONTACT RESISTANCE (OHM-MM)

The resistance between the metallisation and an imaginary plane at the edge of, and perpendicular to, the ohmic metallisation. The value obtained for this parameter, although subject to experimental error, is a true experimentally determined one. The value for contact resistance presented is normalised to ohm-mm.

###### b) SPECIFIC CONTACT RESISTANCE (OHM-CM<sup>2</sup>)

The contact resistance of a unit area for current flow perpendicular to the contact. An assumption underlying the approach used to extract this parameter is that the sheet resistance of the semiconductor under the contact pad is the same as that in the gap between the contacts. Caution should be exercised when assessing the quality of ohmic contacts using this particular parameter

###### c) OHMS PER SQUARE (OHMS or OHMS per SQUARE)

The sheet resistance of the conducting layer of semiconductor between the ohmic contacts. The value obtained for this parameter is a true experimentally determined one.

A full treatment of the theory on which the measurement technique is based is given in Ref (1). To supplement the definitions given above a brief description of the physical principles underlying the technique used in the DP2 system is included in this section.

The DP2 standard test structure consists of 5 ohmic contact pads fabricated on a mesa 100 microns wide. The contact pads are separated by gaps of 5, 10, 15 and 20 microns. The semiconductor surrounding the mesa is semi-insulating and the mesa itself is etched in the same fashion as any device mesas on the wafer. When a voltage is applied between two adjacent ohmic contacts a current flows along one ohmic contact, transfers to the semiconductor and flows across the gap between the pads before transferring out of the semiconductor into the second ohmic contact, fig (11). The total resistance of the circuit described is comprised of the resistance of the semiconductor in the gap between the two ohmic contacts and two equal contributions due to the contact resistance between the ohmic contact pads and the semiconductor, ie:-

$$R_{\text{measured}} = R_{\text{gap}} + 2 \times (\text{contact resistance}) \quad (1)$$

If the separation between the two pads is  $l_g$ , the width of the mesa is  $W$  and the sheet resistance of the semiconductor in the gap is  $R_{SH}$  ohms per square then:-

$$R_{\text{gap}} = R_{SH} \cdot l_g / W$$

equation (1) therefore becomes

$$R_{\text{measured}} = R_{SH} \cdot \frac{l_g}{W} + 2 \times (\text{contact resistance}) \quad (2)$$

At each test site  $R_{\text{measured}}$  can be obtained for several values of  $l_g$ , a straight line fitted to this data will have the following properties:-

$$\text{Slope} = R_{SH} / W \quad (3)$$

$$\text{Intercept on } R_{\text{measured}} \text{ axis} = 2 \times (\text{contact resistance}) \quad (4)$$

The contact resistance and sheet resistance can be obtained from equations (3) and (4). It is usual to quote the contact resistance normalised for a 1mm wide gap, i.e:- normalised contact resistance = (contact

resistance) x W ohm-mm.

In order to obtain a value for the specific contact resistance of the ohmic contact the area of the contact is required. Due to the complex manner in which the current progressively transfers from the ohmic contact into the semiconductor a parameter called the "transfer length", ( $l_t$ ), is defined which corresponds to the length, in the direction of the current flow, over which  $(1-1/e)$  of the current transfers from the contact pad to the semiconductor. This transfer length is measured from the edge of the gap. The effective contact area is therefore  $l_t \times W$ . In order to obtain a value for  $l_t$  it is assumed that the sheet resistance of the semiconductor under the contact pads is the same as the sheet resistance in the gap between the contacts. Equation (2) then becomes:-

$$R_{\text{measured}} = R_{SH} \cdot \frac{l_g}{W} + 2 \times R_{SH} \cdot \frac{l_t}{W} \quad (5)$$

A straight line plot of this data yields the same sheet resistance and contact resistance information as before but allows  $l_t$  to be estimated from the intercept of the fitted line with the  $l_g$  axis.

ie. when  $R_{\text{measured}} = 0$

$$R_{SH} \cdot \frac{l_g}{W} = - 2 \times R_{SH} \cdot \frac{l_t}{W} \quad (6)$$

Cancelling terms in equation (6) gives:-

Intercept on  $l_g$  axis =  $-2 l_t$ .

hence:- Specific Contact Resistance =  $\frac{\text{(Contact Resistance)}}{l_t \times W \text{ ohm-cm}^2}$

In addition to the general contact parameters described above the measured resistances for each gap can be displayed, fig (1) and fig (2). Histograms, grey scale maps and selection maps can be obtained for all parameters allowing the uniformity of alloying, metal deposition etc to be investigated.

In an attempt to eliminate the occasional inconsistent individual gap measurement the data for each test site is examined prior to map plotting. If the measured resistance for a particular gap is higher than the measured resistance for the next (larger) gap then the data set for that particular test site is classed as "invalid data". It should be noted that all measurements are included in the histogram plots for the individual gap resistances.

To allow the quality of the data to be assessed plots of the measured resistances vs gap length can be displayed for each test pattern site. The measured data and the best straight line fitted to the data are displayed as is the correlation coefficient for the fitted line.

The comments made in the section on RESISTANCE regarding parasitic series resistances due to the difficulty of placing probes exactly and reproducibly also apply here. Particular attention should be given to the series resistance due to the high resistivity of the various alloys used to form the contacts. The data analysis relies heavily on accurate values for the interpad gaps, to allow for the inevitable processing variations the default values of 5, 10, 15 and 20 microns can be replaced with accurately measured ones. The facility also exists to change the default mesa width of 100 microns.

iv) FIELD EFFECT TRANSISTORS

The FET parameters extracted are defined in figure (12). Histograms, maps and scatter plots can be obtained for all FET parameters.

Selection maps have proved to be of particular use when investigating FET data and the following abbreviated "device specification" forms a good basis for assessing the true overall yield on a wafer of 200 micron gate width FETs:-

	<u>MIN</u>	<u>MAX</u>
Rslope (Ohms)	5	40
Idsso (mA)	20	60
gm (mS)	15	maximum measured
Igate (microamps)	minimum measured	5

v) DETAILED FET CHARACTERISTICS

This facility is mainly used to provide experimental data to assist in establishing device models. Display options are limited to plots of the measured Vds vs Ids characteristics, figure (13), plots of Ids vs Vgs, figure (14), Gm vs Ids and Gm vs Vgs. For plots other than Vds vs Ids the data can be plotted at a selected value of Vds.

vi) DIODE FORWARD CHARACTERISTICS

The electrical parameters of a Schottky diode can be used to monitor "standard" processing and assess the practical effects of improved or alternative fabrication

processes. This measurement option allows extraction of the ideality, barrier height and series resistance of Schottky diodes. A full mathematical treatment of the measurement can be found in Ref (1) and Ref (2) but as an aid to the user, an outline of the technique used in the DP2 system is given below:-

The simplified equation governing the behaviour of a Schottky diode is taken to be:-

$$I = I_0 \exp \left( \frac{qV}{nkT} \right) \quad (1)$$

I is the forward diode current at forward voltage V  
q is the electronic charge  $1.602 \times 10^{-19}$  Coulombs  
n is the ideality factor  
k is Boltzmann's constant,  $1.38 \times 10^{-23}$  J/K  
T is the absolute temperature, 295K  
I<sub>0</sub> is defined as:-

$$I_0 = \text{Area of diode} \cdot A^* \cdot T^2 \exp \left( \frac{V_B \cdot q}{kT} \right) \quad (2)$$

where A\* is the effective Richardson constant,  $8.4 \text{ A/cm}^2/\text{K}$   
V<sub>B</sub> is the barrier height in eV.

Taking logs of equation (1)

$$\log_e I = \frac{qV}{nkT} + \log_e I_0 \quad (3)$$

A plot of  $\log_e I$  vs V will give a straight line with

$$\text{slope} = \frac{q}{nkT} \quad (4)$$

$$\text{Intercept} = \log_e I_0 \quad (5)$$

The ideality and barrier height are obtained using equations (4), (5) and (2).

The straight line fitting to the measured data can either be carried out automatically by the computer or a fit between two selected current levels can be requested. The automatic fitting routine examines each decade of current and performs a least squares fit on the 10 data points within that decade. A measure of the "goodness" of the fit for each decade is calculated by summing the squares of the deviations in each case. The best straight line for the complete set of data is then assumed to be that line which has the best fit over one decade of the current range. The manual curve fitting routine simply performs a least squares fit to the data between the two values of current selected. The correlation coefficient displayed in the data panel



refers to the best straight line fit over one decade of the linear region of the diode characteristics in the auto fitting mode. The correlation coefficient quoted for manual fitting is for the range selected.

Having selected the best straight line the program then determines the difference, at the maximum forward current, between the actual forward voltage measured and the forward voltage predicted by the fitted line. This voltage difference is assumed to be due to the voltage drop across the series resistance of the diode. Knowing the associated current the series resistance of the diode can be calculated. A plot of the combined diode fit plus series resistance is then drawn for comparison with the measured data, fig (15). It should be noted that in order to obtain the maximum voltage drop across the series resistance the diode forward current should be maximised. Excessive currents through small area Schottky diodes can however cause permanent damage so a compromise value of forward current may have to be used.

The diode I/V measurement can be performed using the auto step facility, histograms and maps of the diode parameters can be displayed in the usual manner.

#### vii) C/V PROFILING

This program is usually used to analyse data obtained from measurements on a standard FATFET. Unless told otherwise the computer assumes the size of the Schottky contact is that of a FATFET, ie 100 x 150 microns. Typical zero bias capacities of FATFETs are in the range 20 pF to 40 pF. C/V measurements have been carried out on real devices with zero bias capacities of 2 to 4 pF, a small number of measurements on smaller capacity devices have successfully been carried out.

The carrier concentration values are extracted from the C/V data using the standard approach as described in Ref (3), it should be noted that no corrections are applied for fringing capacitance or series resistance due to the planar geometry of the FATFET structure. Owing to these series resistance effects doping profiles are likely to be inaccurate at doping levels below  $10^{15} \text{ cm}^{-3}$ .

C/V measurements can be performed across a wafer using the autostep facility, grey scale maps of the carrier concentration near the surface can be produced to indicate variations across the wafer. It should be remembered that the data obtained will contain variations due to non-uniformity of processing in addition to any non-uniformity present in the starting material.

Individual plots of C vs V and Nd vs depth can be obtained by using the mouse to pick the individual device field off a map of all the device fields measured. A display option is available which will allow all the profiles obtained from a wafer to be overlaid in the same display, figure (16). This type of display can sometimes be confusing as the program assumes that any etching has been uniform across the wafer and that all test patterns have been fabricated on the same level. If an absolute depth scale is required a facility is available to add a known etch step to the data.

## 5) SOFTWARE DESCRIPTION

### i) GENERAL

All the programs are written in BASIC Version 4.0 and are initially loaded into memory on power up from a program called (Autost). User interaction with the software is via the computer keyboard and a mouse.

On program start a menu is displayed defining eight softkeys, only two of these softkeys, ie softkey f7 and f8, are active initially, see fig (17). Softkey f7 is labelled ENTER DATA and is used to load the appropriate data file to be analysed. Before the data files can be analysed by the program they must first be converted from the HP 86B disc storage format to the SERIES 300 disc storage format. Soft key f8 is used to select the data conversion program. Once converted the data is stored, in SERIES 300 Format, on a working disc. The HP86 disc is kept as an archive copy.

Assuming all the data files have been converted to the Series 300 computer format then selection of softkey f7 presents a display of the contents of the data disc directory file. Each file name is displayed along with its associated description and probing date. To select a data file the operator is instructed to use the mouse which moves a white band up or down the screen. File selection is made by placing the white band over the file name and description and pressing either of the MOUSE KEYS. Dependant upon the file type selected the relevant subroutine or subprogram is called. These are as follows:-

```
Data Type 'F' Subroutine [Enterfetdata], line 729.
Date Type 'O' Subroutine [Enterohmicdata], line 744.
Data Type 'C' Subroutine [Enterapdata], line 778.
Data Type 'S' Subroutine [Enternewohmic], line 765.
Data Type 'P' line Cvselected,176 Subprogram [Cvplot]
Data Type 'V' line Viselcted,182 Subprogram [Viplot]
Data Type 'I' line Idealitysel,188 Subprogram [Ideal]
Data Type 'R' line Transelected,194 Subprogram [Transline]
```

Should any error occur when a data file is being loaded the program goes to [Initialstart] with a Boolean variable called 'Menucontrol' set 'False'. If the data file is read successfully variable 'Menucontrol' is set 'True'. If 'Menucontrol' is 'False' then the menu only allows selection of the two options selected by softkeys f7) & f8) ie, enter new data or convert data. If 'Menucontrol' is 'True' ie, a data file has been successfully loaded into memory, the following additional softkeys are active from the menu:-

- f1) HISTOGRAM PLOTTING
- f3) MAPPING
- f4) SELECTION MAPPING
- f5) SCATTER PLOTTING
- f6) FAILURE MAP

See fig (18)

A detailed description of each of these options is given in the following sections.

#### ii) HISTOGRAM PLOTTING

On selection of the Histogram option the program goes to Histselect, line 200. A subroutine called [Paramchange] is called which allows selection of the parameters for which the Histogram is to be plotted. For a FET data file the parameters are RSLOPE, IDSS0, GD, VKNEE, GM, IGATE, IDSS4, and VPINCH. A capacitance file has two selectable parameters, CAPACITANCE and CONDUCTANCE. Selection of a parameter is made by softkey in subprogram [Selectparam], line 1909, which is called up from subroutine [Paramchange]. When a parameter has been selected a variable called 'Paramcase' is given a fixed value to identify the selection. In subroutine [Paramchange] the value of 'Paramcase' determines which data is placed in a variable array called 'Fetval'. The maximum and minimum values are stored in variables 'Devmax' and 'Devmin'. The string variable 'Param\$' stores the data for plot titles. The array 'Fetval' is a common array available to all subprograms.

After selecting a parameter the program enters the subprogram [Histogram], line 1453. A data array called 'Value' is allocated and a default boxsize is given to variable 'Boxsize' according to the value in variable 'Hmax', program lines 1469 to 1474. The measured parameter values in array 'Fetval' are extracted, sorted into numerical order and then stored in the sorted form in an array called 'Value'. The histogram box filling routine takes the form of a program loop between lines 1496 and 1506. On entry into this loop a pass window is defined of size minimum value to minimum value plus 'Boxsize'. This window is compared against the sorted array 'Value' to determine the number of device measurements that occur within the window. The number of devices that occur in the

window variable 'Numbox' are then stored in an array called 'Box'. In the loop the upper and lower boundaries of the window are incremented by 'Boxsize' and the process is repeated until the window exceeds the maximum measured value or the number of devices in the array 'Box' equals the total number of devices measured. The array 'Box' is then plotted graphically on the colour monitor screen as a histogram. The default scale for the 'X' axis is minimum = 0, maximum = variable 'Devmax'. The scale for the 'Y' axis is determined by the highest value of the variable 'Numbox'.

A typical histogram display is shown in figure (1).

After the histogram has been plotted five softkeys are allocated to a Histogram menu from which the user can select the following options:-

- f1) RETURN TO MAIN MENU
- f2) UNUSED
- f3) CHANGE BOXSIZE i.e. 10, 5, 1, .5, .1, OR .01
- f4) EXPAND X OR Y AXIS
- f7) PLOTTER COPY
- f8) PRINTER COPY

Selection of softkey f1) aborts the histogram plotting routine and returns the program back to the main menu. Softkey f3) allows the boxsize to be changed. Once the boxsize has been changed the box filling routine described earlier is repeated with the new value for "Boxsize", the results are displayed on the screen as before. Softkey f4) allows selected regions of the 'X' and 'Y' axes to be plotted. Selection of softkey f4) calls subprogram [Enter maxmin], line 3032. This subprogram allows new 'X' and 'Y' maximum and minimum values to be entered. Exit from the subprogram is by softkey f1) which is allowed only if the maximum values entered are greater than the minimum values entered. On exit from the subprogram the histogram is automatically redrawn with the new axes.

Selecting softkey f7) produces a hard-copy plot of the screen display drawn on a six colour pen plotter. Softkey 'f8' performs a screen dump to an inkjet printer which is monochrome only.

#### iii) GREY SCALE MAP

The map is plotted to a default scale held by the variables 'Devmax' and 'Devmin' of the selected parameter. Seven intensities or seven shades of grey are used to represent the data. The window for each intensity or shade of grey is calculated by subtracting the minimum value 'Devmin' from the maximum value 'Devmax' and dividing the result by seven. Seven windows are therefore created into which the data can be slotted, the values being held in variable array 'Inc'. The map is plotted within a double

loop in the program. The number of times the first loop is repeated is determined by the number of device columns (variable 'Xcol'). The number of times the second loop, which is inside the first loop, is repeated is determined by the number of device rows (variable 'Yrow'). Each increment of the loop corresponds to the measured device data and position. Program lines 1108 to 1176 show the comparison of the measured device data to the window variable 'Inc'. The result of each comparison is a shade of grey value held in variables 'Areapen' and 'Areaint'. A rectangle is then plotted on the colour monitor screen and shaded with the value held in variable 'Areapen'. Figures 3, 4 and 5 show completed maps with offwafer devices being represented by a red rectangle with a diagonal slash. Once the map has been completed a subprogram called [Mapscalenum], line 2787, is called to draw in the device numbers. On completion of the map drawing eight softkeys are defined as follows:-

- f1) :- RETURN TO MAIN MENU
- f2) :- CIRCULAR MAP
- f3) :- SAMPLE MAP
- f4) :- CHANGE MAX-MIN
- f6) :- PLOTTER SHADING
- f7) :- PLOTTER NUMBERS
- f8) :- PRINTER COPY

Softkey f1) performs the same functions as in the histogram routine. Selection of softkey f2) re-plots the wafer map using anisotropic scaling as opposed to the default isotropic scaling. The result of this is to produce a rounded map from an elliptical map. Subprogram [Mapint], line 3192 is called to set up the scaling as determined by Boolean variable 'Circ'.

Selecting softkey f3) re-plots the wafer map using isotropic scaling. Selection of softkey f4) calls subprogram [Maxmin], line 1973. This subprogram allows the maximum and minimum values of the parameter being mapped to be altered. If the maximum value entered is greater than the minimum value entered the wafer map is automatically re-drawn. If the maximum value entered is less than the minimum value then an error is reported and the program will not continue until the maximum and minimum values are entered correctly.

Selection of softkey f6) uses the system plotter to plot the wafer map with shaded rectangles to represent the grey scale intensities. Subprogram [Plotter-shade], line 3275, is called to perform this task.

Selection of softkey f7) draws the plot on the system plotter with numbers instead of intensities to represent the parameter values. The numbers are 1, 2, 3, 4, 5, 6 and 7, with 7 corresponding to white.

Selection of softkey f8) dumps the screen image to the

line printer. It should be noted that the printer image is the inverse of the screen image i.e. white on the screen is black on the printer. Selection of softkey f8) turns off the colour mode used to draw the wafer map and re-draws the wafer map on the screen with a seven level intensity scale. The reason for drawing with intensities is to allow the screen to be dumped to the system printer. With the existing system printers it is not possible to dump full grey scale or colour images but a future option may be to connect the computer to a colour video printer.

The grey scale is inverted on the screen so that the screen dumped image corresponds to the original grey scale wafer map on the screen, the original screen display is automatically recalled on completion of the screen dump.

#### iv) SELECTION MAPS

Selecting softkey f4) in the main menu calls up a selection mapping routine. This routine allows the operator to specify a particular combination of device parameters and form a device "data sheet". Each device is compared against the "data sheet" and the locations of those which fit are then plotted in the form of a wafer map. The subroutine [Limitmapf], line 2018, is used to carry out this selection process. At present only data files type 'F' (FETs), 'O' (OHMICs), and 'C' (Capacitors) can be selection mapped.

Subroutine [Limitmapf] displays a table containing the "data sheet" parameters alongside the measured maximum and minimum values of each parameter. The parameter to be changed is selected using the mouse and the required maximum and minimum values for that parameter are entered using the keyboard. The selected maximum and minimum limits are stored in a variable array called 'Lim2'. Subroutine [Passvalues], line 906, uses the array 'Lim2' to determine which devices pass the selected limits. The results are stored in an array called 'Passval'. A device that fails the selected limits is given the value -20 whilst a device that passes is given a value of 1.

Once the subroutine [Passvalues] has been completed subprogram [Mapping\_limits], line 2697, is called. This subprogram plots the array 'Passval' in the form of a wafer map. Once the map has been plotted eight softkeys are allocated from which the user can select the following options:-

- f1) :- RETURN TO MAIN MENU
- f2) :- CHANGE LIMITS
- f3) :- RESET LIMITS
- f4) :- PRINTER COPY OF DEVICES PASSED
- f5) :- SELECT DEVICE
- f7) :- PLOTTER COPY
- f8) :- PRINTER COPY

Selection of softkey f2) permits the maximum and minimum pass/fail limits to be changed again if required. The pass/fail limits can be reset to the default maximum and minimum values by selection of softkey f3).

A printer copy of the measured data for all the devices which fit the "data sheet" can be obtained by selecting softkey f4). Selection of softkey f5) stores the screen map in an array called 'Gscreen'. A routine is then entered which allows selection of an individual device from the plotted map. Selection of a device is made via the mouse and subprogram [Pickdev], line 2634. Only a device that has passed can be chosen. Once a device has been selected the following options are available:-

- f1) :- RETURN TO MENU
- f4) :- PRINT DEVICE DATA
- f5) :- IDS PLOT
- f6) :- SELECT DEVICE
- f8) :- PRINTER COPY

Softkey f4) provides a printout of the measured data for the device selected. Selection of softkey f5) is only possible if the data is of type 'F' ie, FET measurement data. If softkey f5) is selected with a FET data file then a simplified characteristic curve of the device is plotted on the screen. An example of this simplified curve is shown in figure (19). A printer copy of the screen picture can be obtained by selecting softkey f8). Selection of softkey f6) redraws the memorised selection wafer map from array 'Gscreen' and allows another device to be selected. Softkey f7) provides a plotter copy of the screen picture.

#### v) SCATTER PLOTTING

Data files containing at least two measured parameters can be scatter plotted. When the scatter mode is selected the operator is instructed to select the 'X' axis parameter. This is achieved in line 501 where subroutine [Paramchange] is called. The operation of subroutine [Paramchange] is described in the section on Histogram plotting. After selecting the 'X' axis parameter the array called 'Passval' is used to hold the measured data. The program then asks the operator to select the 'Y' axis parameter. The 'Y' axis measured data is retained in the array 'Fetval'.

After choosing the parameter axes subprogram [Scattermap], line 1732, is called. This subprogram scales and sets up the axes and then plots the selected parameters against each other. On completion of the plot the following scatter mode menu is active via the softkeys:-

```

f1) :- RETURN TO MAIN MENU
f2) :- RESET RE-PLOT
f3) :- LOG X/Y AXES
f4) :- EXPAND X/Y AXES
f5) :- CHANGE PARAMETER
f6) :- OVERDRAWMODE
f8) :- PRINTER COPY

```

Selection of softkey f1) aborts the scatter plotting mode and returns the program to the main menu. Selection of softkey f3) redraws the scatter plot with logarithmic axes. Both axes at present are drawn with logarithmic scales. Selection of softkey f4) calls subprogram [Entermaxmin] to change the 'X' or 'Y' axis scaling. Figure (10) is a photo of the screen display of a typical scatter plot. Selection of softkey f6) allows the operator to enter a different data file and overlay the data stored on screen with the new data. Selection of softkey f2) cancels the overdrawmode and resets the screen to a scatter plot of the parameters selected for the last data file entered.

#### vi) FAILURE MAPS

This option plots a map of the devices which were classed as failed devices during the original probing run, the map also identifies the nature of the failure. If the devices are FETs then the array 'Fetval' is automatically filled with the values of the 'Vpinch' array. As described in part 1 of this memo failures are identified by suitable tokens which are stored in the 'Vpinch' array. Subprogram [Failuremap], line 2163, plots the failure map. Coloured rectangles are used to distinguish the different failures. Figure (6) is a photo of the screen display. If a printer copy is requested then subprogram [Printfailmap], line 2877, is called and instead of coloured squares to identify failures, characters are used. Once a failure map has been plotted the following softkeys are redefined for the failure map mode:-

```

f1) :- RETURN TO MAIN MENU
f2) :- CIRCULAR MAP
f3) :- SAMPLE MAP
f6) :- PLOTTER COLOUR
f7) :- PLOTTER LETTERS
f8) :- PRINTER COPY

```

Selection of softkey f6) calls subprogram [Color\_failmap], line 3399. This subprogram produces a failure map on the system plotter using coloured rectangles and shading to distinguish between different failures. Figure (21) shows an example of the coloured plotter failure map. Selection of softkey f7) produces an alternative plotter output using the same character set as the printer. A typical plotter display is shown in figure (20).



#### vii) C/V MEASUREMENTS

If a data file type 'P' (C/V measurement) has been selected subprogram [Cvplot] is automatically loaded and executed. This subprogram starts by reading the disc data file and placing the measured data into a variable array called 'Cv'. A subroutine called [Cvmap], line 300, is then called which plots a wafer map of the devices measured. Devices with valid measurement data are distinguished by being plotted with blue rectangles. The following options are available when the wafer map has been plotted:-

- f1) :- RETURN TO MAIN MENU
- f2) :- Nd MAP
- f3) :- CHANGE AREA
- f4) :- Cv DATA MAP
- f5) :- SELECT DEVICE
- f8) :- PRINTER COPY

Selection of softkey f1) aborts the CV plotting routine and returns the program to the main menu. Selection of softkey f2) plots a grey scale Nd map using subprogram [Mapsub] as described under Grey Scale mapping. The Nd values displayed are calculated using the zero bias data only. The map scale is derived by subtracting the minimum Nd value from the maximum Nd value and dividing the result by 7. The default area, variable 'Area' used in the CV calculations [Calcv], line 509, is  $1.5 \text{ E-4 cm}^2$ . Selection of softkey f3) allows this area to be changed. Selecting softkey f5) calls subprogram [Pickdev] which utilises the mouse to select a specific device. Only devices with valid data are allowed to be selected by the program.

Once a device has been selected, two softkeys are redefined as follows:-

- f4) :- Nd Profile
- f5) :- Cap/Volt Plot

Selection of softkey f4) calls subroutine [Calcv], line 509 which calculates the Nd data and stores the results in an array called 'Nd' and an array called 'Depth'. Subroutine [Cvdraw], line 432 is then called and 'Nd/cc' is plotted against 'Depth'. On completion of the 'Nd/cc' plot a submenu [Submenu1], line 108, is available to select any of the following options.

- f1) :- CV Menu
- f3) :- X-Y Axis Expand
- f4) :- Add Etch Step
- f5) :- Overlay Allplots
- f8) :- Printer Copy

Selection of softkey f1) returns the program to the original CV Menu options, line 44. Softkey f3) uses Subprogram [Entermaxmin] to allow selected regions of the data to be plotted. Softkey f4) allows the etch step variable 'Etstep' to be changed. The default value for the etch step is 0. Softkey f5) allows all the valid device data to be overlayed on one plot. Softkey f8) provides a printer copy of the screen picture.

Selecting the Cap/Volt Plot option using softkey f5), plots the measured capacitance against the measured voltage of a selected device. Subroutine [Capvoltplot], line 375 is used to plot the capacitance/voltage data with the selected device number stored in variable 'Devnum'. On completion of the plot the softkeys are redefined as follows [Submenu2], line 197.

```
f1) :- CV Menu
f3) :- X-Y Axis Expand
f5) :- Overlay Allplots
f8) :- Printer Copy
```

These options perform the same functions as those described under [Submenu 1].

#### viii) DETAILED FET V/I

When a data file type 'V' (FET voltage - current characteristic) has been selected the program automatically loads and executes subprogram [Viplot]. The subprogram starts by entering all the measured data from the type 'V' disc data file into an array called 'Reading'. The measured voltage and current values are then extracted from the array 'Reading' and placed in arrays 'Vds' for voltage values and 'Ids' for the current values. The softkeys are then defined with the following options:-

```
f1) :- RETURN TO MENU
f2) :- IDS/VDS PLOT
f3) :- GM/VGS PLOT
f4) :- IDS/VGS PLOT
f5) :- GM/IDS PLOT
f8) :- PRINTER COPY
```

Selection of softkey f1) aborts subprogram [Viplot] and returns the program to the main menu.

Softkey f2) IDS/VDS PLOT:- This calls subroutine [Vidraw], line 282, to plot the measured drain-source voltage against the drain- source current.

Softkey f3) GM/VGS PLOT:- Selection of this option first requires a drain-source voltage to be selected. Subroutine [Selectvds], line 101, allows selection of one of the following voltages 1.5 V, 2 V, 2.5 V, 3 V, 3.5 V, 4 V,

4.5 V and 5 V. The selected voltage is stored in variable 'Voltds'. Having selected a voltage, subroutine [Gmplot], line 181, is then called. The 'Gm' is calculated by subtracting two consecutive values from the array 'Ids' and dividing the result by the measurement voltage step, variable 'Vstep'. This is repeated for all the records and the results stored in the array called 'Gmp'. The subroutine [Gmplot] then plots the Gm values from the array 'Gmp' against the gate voltage. It should be noted that the gate voltages are not directly measured during probing and the variable 'Vstep' contains the increments called up by the probing computer.

Softkey f4) IDS/VGS PLOT:- Selection of this option first requires the operator to select a drain-source voltage as previously described. Subroutine [Vgplot], line 139, is then called to plot the drain-source current against the gate-source voltage.

Softkey f5) GM/IDS PLOT:- Selection of this option first requires the operator to select a drain-source voltage as previously described. The subroutine [Gidsplot], line 232, is then called to plot the Gm against the drain-source current. The Gm values are calculated as described under "Gm/Vgs" plot.

#### ix) DIODE FORWARD I/V

When a data file type 'I' has been selected the program automatically loads and executes subprogram [Ideal]. The subprogram starts by entering all the measured data from the type 'I' disc data file into an array called 'Id'. Each element of the array contains the measured I/V data for one diode. Subroutine [Idmap], line 452 is then called to display a wafer map on the screen. Devices with valid measurement data are distinguished by being plotted with blue rectangles. The following options are available upon completion of the wafer map:-

- f1) :- RETURN TO MAIN MENU
- f3) :- HISTOGRAMS
- f4) :- MAPS
- f5) :- SELECT DEVICE
- f8) :- PRINTER COPY

Selection of softkey f1) aborts the subprogram and returns the program to the main menu. Selection of softkey f3) and softkey f4) call the subprogram [Histogram] and grey mapping subprogram [Mapsub]. Before either histograms or grey scale maps can be produced the subroutine [Fillarray] is used to calculate the Ideality factor, Barrier height and Diode series resistance for each device measured. [Fillarray], line 258, uses the automatic line fitting routine [Autocurve], line 169, to determine the slope and intercept of the linear portion of the diode characteristic for each

individual device measured. In order to determine the best straight line fit to the measured device data [Autocurve] splits the data into consecutive groups of ten readings. The least squares program functions, [Lsq1] and [Lsq2] are used to determine the intercept, slope and deviation of each of these groups of readings. The best straight line fit to the linear region of the diode characteristic is assumed to be the line fitted to the group with the smallest deviation. The Barrier Height and Ideality are obtained using the program functions [Ideal\_ity] and [Barrier\_hgt]. The voltage difference, at the maximum forward current, between the value predicted by this fitted line and the actual value measured is divided by the maximum forward current to give the diode series resistance. When the curve fitting and parameter calculation for each of the devices measured is complete a Boolean variable 'Devdata' is set True, this then enables the Histogram and Mapping subprograms. Histograms and Maps of Ideality Factor, Barrier Height and Diode Resistance can be produced.

Selection of softkey f5) labelled 'Select Device' calls subprogram [Pickdev] which utilises the mouse to select a specific device. Providing the device selected contains valid data then the program calls subroutine [Plotideal], line 327. This subroutine plots the device current/voltage characteristic on the screen, see fig (15). On completion of the plot the following options are available:-

- f1) :- I/V MENU
- f3) :- AUTO CURVEFIT
- f4) :- MANUAL CURVEFIT
- f5) :- CHANGE AREA
- f6) :- SELECT DEVICE
- f7) :- PLOTTER COPY
- f8) :- PRINTER COPY

Selection of softkey f1) returns the subprogram to the initial set of options previously described. Selecting softkey f3) calls [Autocurve] which carries out the curve fitting and parameter calculations described earlier in this section and obtains values of the Barrier Height, Ideality and Diode Resistance for the device. A plot of the fitted diode equation is then drawn superimposed on the measured data and the Barrier Height, Ideality, Diode Resistance, correlation coefficient for the linear region and fitting coefficient for the complete characteristic are displayed in the data panel. The fitting coefficient displayed is the sum of the absolute values of the differences between the measured and fitted voltages.

Selecting softkey f4) allows the operator to define the region over which the straight line fitting is to be carried out. The program performs a least squares straight line fit to all the data points within the selected region. The diode parameters and fitting coefficients are displayed in

the data panel as before.

x) TRANSMISSION LINE OHMIC MEASUREMENTS

When a data file type 'R' has been selected the program automatically loads and executes subprogram [Transline]. The subprogram starts by entering all the measured data into four array's called 'Arry20', 'Arry15', 'Arry10' and 'Arry5'. Subroutine [Caltrans], line 422, is then called to calculate the Contact Resistance, Specific Contact Resistance and Ohms Per Square values for each set of valid readings. Subroutine [Caltrans] performs a least squares fit on the data as shown by program lines 434, 435. These values are stored in arrays called 'Conres', 'Spcon' and 'Ohmsq'. A subroutine called [Devmap], line 346 is then entered to display a wafer map, on the screen, of devices with valid data. Devices with valid measurement data are distinguished by being plotted with blue rectangles. The following options are available upon completion of the wafer map.

- f1):- RETURN TO MENU
- f2):- CHANGE GAP SIZE
- f3):- HISTOGRAMS
- f4):- MAPS
- f5):- SELECT DEVICE
- f6):- DEVICE OVERLAY
- f8):- PRINTER COPY

Selection of softkey f2) allows the default gap sizes of 20 microns, 15 microns, 10 microns, 5 microns and the default width of 100 microns to be changed in variables 'G20', 'G15', 'G10', 'G5' and 'Wide'. Selection of softkey f3) calls subprogram [Histogram]. Selection of softkey f4) calls subprogram [Mapsub]. Both of these subprograms have been described previously in this memo. Histograms and Grey Scale maps of the following parameters can be plotted: 20 microns, 15 microns, 10 microns, and 5 microns gap resistances, the Contact Resistance, Specific Contact Resistance and Ohms per Square of the semiconductor between the ohmic pads.

Selection of softkey f5) calls subprogram [Pickdev] which utilises the mouse to select a specific device from the wafer map. Upon selection of a device subroutine [Plottrans], line 198 is entered. This subroutine plots the measured four gap ohmic readings together with the best straight line fit to the data, see figure (22). A correlation coefficient is calculated and displayed on the plot.

Selection of softkey f6) uses subroutine [Plottransall], line 250. This subroutine provides a screen plot of all the valid device gap resistances together with the best straight line fits all on one plot. Figure (23) shows an example of the overlaid screen plot. Subroutine

[Plattransall] also initialises array 'Passval' with all the calculated correlation coefficients. The array can be analysed in the Histogram and Grey scale mapping subprograms. The Boolean variable 'Correlation' is used to enable the 'Passval' array.

#### xi) DATA CONVERSION

The program that converts disc data files from the HP86 computer to the Series 300 computer is called [Convertdat]. This is a complete program which is loaded automatically from the display program when selected. The program starts by first reading the disc data file called [Directory] and converting it to the Series 300 format. Subprogram [Datamenu], line 640, uses the directory to display the disc data file information on the screen. Selection of a data file is made by moving a white band over the file name via the mouse. On selection of a data file the following options are available:-

- f1):- CONTINUE & CONVERT
- f7):- RE-SELECT
- f8):- RE-START

On selecting softkey f1) various error checking routines ensure valid data discs, valid directories and no duplicate file names exist. The actual conversion subprogram is called [Conversion], line 718. Default data file record lengths are given to variable 'Reclength' as described in part 1 of this memo. The subprogram initially converts the first two numbers of the data file i.e. number of columns 'Xcol' and number of rows 'Yrow'. From these variables the total number of numbers to be converted is calculated. Subroutine [Convertnum], line 805, actually converts the numbers. On completion of the number conversion the data is stored on a Series 300 data disc with the corresponding directory information updated. The following options are then available:-

- f1):- SELECT & REPEAT
- f2):- CHANGE 86 DATA DISC
- f5):- READ 300 DIRECTORY
- f6):- DELETE FILE
- f8):- ANALYSE DATA

Selecting softkey f8) aborts the conversion program and automatically re-loads the display program [Displaydat].

#### 6) CONCLUSIONS

The decision to separate the two functions of the auto prober system has proved sound and has effectively removed the bottleneck at the measurement stages of wafer processing. The sophisticated graphics available have proved ideal for displaying data and the speed of the HP300 computer has allowed a useful

interactive facility to be realised. The technique of accessing the display options by selection from a menu made very stringent demands on the structure of the software but the resulting facility has proved effective and popular as well as being easy to use. At the present time the hard copy printouts of screen maps do not reflect the quality and impact of the actual screen displays and this aspect of the facility deserves further investigation.


The system described in these two memos has been in regular use for the past eighteen months and has proved to be an invaluable tool in the device and device technology program of the division. The large increase in the speed at which devices are measured has enabled full device data to be gathered on large wafers allowing fine detail as well as general trends to be investigated. An additional benefit of the system has been the increased precision of the data compared to that previously obtained using a manual curve tracer. In addition to the speed and precision benefits of the measurement system the computer data handling has allowed full advantage to be taken of the large volume of high quality data available. The complete system has now become an essential part of the DP2 processing facilities.

#### 7) ACKNOWLEDGEMENTS

Although all the software described in these memos was written specifically for this autoprobing system three of the routines used are based on sections of programs which already existed within DP2 Division. We would like to acknowledge these contributions from the following individuals: J Birbeck, D Lee and J Smith for the routine used to extract Nd and depth in the C/V profiling programs, K Hilton and G Pryce for the basis of the curve fitting routine used in the diode I/V measurements and J Gaskell for supplying the routine originally used to convert the data from HP86 format to HP300 format. Finally we would like to acknowledge the helpful discussions with J Woodward and the co-operation of the rest of the processing section in carrying out the field testing of the system.


#### 8) REFERENCES

- Ref (1) R E Williams, "Gallium Arsenide Processing Techniques", publ. by Artech House, inc. 1984.
- Ref (2) V L Rideout, Thin Solid Films, 48 (1978) 261-291.
- Ref (3) S M Sze, "Physics of Semiconductor Devices", 2nd Ed. publ. by Wiley-Interscience, 1981.




**FIGURE 1 TYPICAL HISTOGRAM PLOT OVER FULL DATA RANGE**







**FIGURE 2 DETAILED HISTOGRAM PLOT OVER SELECTED DATA RANGE**




**FIGURE 3 GREY SCALE MAP OVER FULL DATA RANGE**




**FIGURE 4 GREY SCALE MAP, DATA RANGE FROM 10 mA TO 80 mA**




**FIGURE 5 GREY SCALE MAP, DATA RANGE FROM 30 mA TO 40 mA**



**FIGURE 6 EXAMPLE OF FAILURE MAP**



**FIGURE 7 FET SELECTION MAP FOR  $I_{DSS0}$  RANGE 20 mA TO 30 mA**



**FIGURE 8 FET SELECTION MAP FOR  $I_{DSS0}$  RANGE 30 mA TO 40 mA**





FIGURE 9 FET SELECTION MAP FOR  $I_{DSS0}$  RANGE 40 mA TO 50 mA





**FIGURE 10 TYPICAL SCATTER PLOT**





FIGURE 11 CONTACT RESISTANCE MEASUREMENT




$$R_{slope} = \frac{0.2}{I_1} \quad ; \quad G_d = \frac{(I_3 - I_2)}{5 - 2} \quad \therefore I_{dsso} = I_3$$

$$g_m = 2(I_3 - I_4)$$

FIGURE 12 DEFINITION OF MEASURED FET PARAMETERS

13 Jul 1987 EPI LAYER MRS14 FET100 NO 4611

# F1004611V IDS/VDS CURVE



RSLOPE=13.36 OHM  
IDSS0 =58.32mA  
GD =.01mS  
VKNEE =.7844V  
GM =28.09mS  
IGATE =.095uA  
IDSS4 =.009mA  
VPINCH=1.6V

VOLTAGE STEP=.1V


Probed by:-BTH  
Probed on:-04/11/86  
TIME:-11:18:06  
\*-DP2 DIVISION-\*  
\*-RSRE MALVERN-\*

FIGURE 13 DETAILED FET CHARACTERISTICS,  $I_{ds}/V_{ds}$  PLOT

13 JUL 1987 EPI LAYER MR514 FET100 NO 4611

F1004611V  
Ids/Vgs PLOT

VDS=5V



Probed by: -BTH  
+1 Probed on: -04/11/86  
TIME: -11:22:14  
\*-DP2 DIVISION-\*  
\*-RSRE MRLVERN-\*

FIGURE 14 DETAILED FET CHARACTERISTICS  $I_{DS}/V_{GS}$  PLOT





FIGURE 15 DIODE FORWARD CHARACTERISTIC PLOT

27 Jul 1987 RH FATFET ON MMT78 26BT EVERY FOURTH DEVICE

MT7826P

Nd PROFILE



DEVICE NUMBER

16 16

Nd/cc

Plotted against

Depth(Microns)

ETCH:-0uM

FREQUENCY:-.01MHz

AREA:-.00015cm^2

Probed by:-BTH


Probed on:-07/05/86

TIME:-14:33:02

\*-DP2 DIVISION-\*


\*-RSRE MFLVERN-\*

FIGURE 16 OVERLAY OF FATFET C/V PROFILES



**FIGURE 17 EXAMPLE OF MENU DISPLAY BEFORE A DATA FILE HAS BEEN SELECTED**






**FIGURE 18 EXAMPLE OF MENU DISPLAY AFTER A DATA FILE HAS BEEN SELECTED**

21 Aug 1987 LH MFET ON REF1 (PUN 8061 Z034)

DIAGRAMMATIC ONLY

# LMFETF IDS/VDS CURVE



COLUMN:-7 ROW:-4  
RSLOPE=61.1 OHM  
IDSS0 =19.28mA  
GD =.6521mS  
VKNEE =1.1V  
GM =13.41mS  
IGATE =3.263uA  
IDSS4 =.004mA  
VPINCH=1.9V

Probed by:-BTH  
Probed on:-13/03/86  
TIME:-14:10:41  
\*-DP2 DIVISION-\*  
\*-RSRE MALVERN-\*

FIGURE 19 EXAMPLE OF DIAGRAMMATIC  $I_{DS}/V_{DS}$  CURVE OF FET OBTAINED IN SELECTION MAP MODE

[illegible]

```


o :- INVALID DATA
[ ] :- OFF WAFER
R-RSLOPE >500 OHM
S=SHORT <1 OHM
I-IDSS0 >200 mA
D=Gd FAIL
K=VKNEE >3 V
T=Gm <.2 mS
G=GATE I >100 uA
V=VPINCH >4V @20mA
◇ DEVICES PASSED

```

Probed by:-JTP  
Probed on:-02/06/07  
TIME:-09:47:15  
\*-DP2 DIVISION-\*  
\*-RSRE MALVERN-\*

**FIGURE 20 PLOTTER COPY OF FAILURE MAP USING CHARACTERS**

24 Aug 1987 V PINCH SET AT 20 MA



# FET102AF FAILURE MAP

o :- INVALID DATA  
 [ ] :- OFF WAFER  
 [ ] RSLOPE >500 OHM  
 [ ] SHORT <1 OHM  
 [ ] IDSS0 >200 mA  
 [ ] Gd FAIL  
 [ ] VKNEE >3 V  
 [ ] Gm <.2 mS  
 [ ] GATE I >100 uA  
 [ ] VPINCH >4V @20mA  
 [ ] DEVICES PASSED

Probed by:-JTP  
 Probed on:-02/06/87  
 TIME:-10:01:30  
 \*-DP2 DIVISION-\*  
 \*-RSRE MALVERN-\*

FIGURE 21 PLOTTER COPY OF FAILURE MAP USING COLOURED RECTANGLES AND SHADING




FIGURE 22 PLOT OF INDIVIDUAL TRANSMISSION LINE OHMIC MEASUREMENT,  
SELECTED FROM WAFER MAP




FIGURE 23 PLOT OF TRANSMISSION LINE OHMIC MEASUREMENTS FOR WHOLE  
WAFER

## DOCUMENT CONTROL SHEET

Overall security classification of sheet **UNCLASSIFIED**

(As far as possible this sheet should contain only unclassified information. If it is necessary to enter classified information, the box concerned must be marked to indicate the classification eg (R) (C) or (S) )

1. DRIC Reference (if known)	2. Originator's Reference MEMO 4066	3. Agency Reference	4. Report Security Unclassi-Classification fied	
5. Originator's Code (if known) 778400	6. Originator (Corporate Author) Name and Location RSRE, Saint Andrews Road, Malvern, Worcs WR14 3PS			
5a. Sponsoring Agency's Code (if known)	6a. Sponsoring Agency (Contract Authority) Name and Location			
7. Title AUTOMATIC PROBER FOR THE DC CHARACTERIZATION OF GALLIUM ARSENIDE DEVICES, PART 2. THE DATA SORTING & DISPLAY FACILITY.				
7a. Title in Foreign Language (in the case of translations)				
7b. Presented at (for conference papers) Title, place and date of conference				
8. Author 1 Surname, initials HUGHES B T	9(a) Author 2 AVERY B E	9(b) Authors 3,4...	10. Date 1987. 07	pp. ref.
11. Contract Number	12. Period	13. Project	14. Other Reference	
15. Distribution statement				
Descriptors (or keywords)				
continue on separate piece of paper				
<b>Abstract</b> The Automatic Device Probing System used in the Microwave Devices Division (DP2) comprises separate measurement and data handling facilities. The measurement facility is described in RSRE Memorandum 4065 and the data sorting and display facility forms the subject of this memorandum.  The facility described is designed to assist in analysing the large quantity of measured data obtained from device wafers and allows general trends as well as individual device parameters to be investigated. Programs have been written to produce maps which allow parameter variations across wafers to be assessed and additional routines are available which present the data in histogram form.  Continued overleaf ...				

Abstract from Memo 4066 continued.

These options allow the numeric as well as the geographic distribution of the data to be investigated. Three main types of map display are available, these display the variation in magnitude of a device parameter across a wafer, the location and nature of the failure of any failed devices and the location of devices with a specified combination of parameters. The histogram programs allow the data range and class interval to be adjusted enabling estimates of yield and process control to be made. For measurements such as Capacitance/Voltage on Schottky test patterns or current/voltage on active devices plots of the measured data can be displayed. Routines are available which allow curve fitting to the measured data so that barrier heights etc can be extracted.

Full use has been made of colour and grey scales in order to maximise the visual content of the information presented on the display screen and all display modes are easily selected using a combination of menus and softkeys.



DAT  
FILM  
8